



Models 1006M / 1007M Retro Bench

Parts Listing



WEIGHT CAPACITY: 500 lbs. Per Bench

Assembly Notes:

During assembly, hand tighten screws only. When all screws are in place, you may then tighten all screws completely.

CAUTION:

1. Check for loose screws and tighten them every 6 months.

Assembly Instructions

Tools Needed: Adjustable Pliers, Allen Wrench
Please read all instructions before assembly.

- Step 1:** Slide Post Covers (F) over legs of H-Frames (B) as shown.
- Step 2:** Screw in Anchoring Plates/Leveling Glides (G) to bottom of H-Frame legs (B).
- Step 3:** Align holes in H-Frames (B) with the corresponding holes in the Cross Bar (C). Insert 10x75mm Bolts (H) through the 56mm Bolt Sleeves (K) and into the 10mm Nuts (O) for vertical connections. Insert 10x55mm Bolts (I) through 36mm Bolt Sleeves (J) into the Nuts (O) for horizontal connections. Tighten with Allen Wrench and Pliers.
- Step 4:** Align Bench Brackets (E) with H-Frames (B) and attach using 10x25mm Screws (M) and 10mm Nuts (O). Tighten with Allen Wrench.
- Step 5:** Align Benches (D) with Bench Brackets (E) and attach using 8x12mm Screws (L). Tighten with Allen Wrench.
- Step 6:** Align Table Top (A) with Cross Bar (C) and attach using 10x12mm Screws (N). Tighten with Allen Wrench.

ofm
Furniture For The Real Office™

161 Tradition Trail, Holly Springs, NC 27540
800-520-7471 (voice) 919-362-4765 (fax)
919-303-6389 (voice) www.ofminc.com
support@ofminc.com